

UNEQUAL[®]
SOLO[™]
Easy install instructions



#BATTLEREADY
UNEQUAL.com

Before you start:

- Read these instructions and warning in full before proceeding.
- Remember, SOLO is supplemental padding. Do not remove the helmet manufacturer's original padding or peel apart the layers of the SOLO.
- SOLO does not adhere directly to the helmet; there is no adhesive.

To optimize fit:

SOLO can be customized to the exact shape of your helmet. It is designed for a large to extra-large helmet, so you may need to trim it to best fit into your helmet:

Step 1

Align the large "roundish" tab with the front of the helmet pad. Place the SOLO inside the helmet and press it into place.



Step 2

Use a pen to mark parts of the SOLO that exceed the sides of the helmet. Do not trim the front tab.

Step 3

Use a pen to mark parts of the SOLO that overlap. Mark only the sides or the back pieces. Do **not** trim the front "roundish" tab.

Step 4

Using normal sharp scissors, or a straight edge, cut the excess and the areas of overlap. Place back into the helmet.

Step 5

With SOLO inside the helmet, face the open part of the helmet toward your body with your arms at a 90° angle. Lower your head and bend toward the helmet to prevent the SOLO from becoming displaced. Once your head is completely inside of the helmet, stand upright.

Care instructions:

Remove from helmet and hand wash with soap and lukewarm water. Do not submerge the SOLO into water. Air dry.